

# CLEAR BRA INSTALLATION TIPS

**Modern Clear Bra film is offered in varying qualities and thicknesses. Typical of the superior quality variations is a urethane composition and glossy clear coat finish.**

## PRE PURCHASE

At 6 Milli-inches (a.k.a. 6 Mils), and up, modern clear bras are equally thick as paint.

They offer a pliable and impact absorbent surface that will protect against road debris.

The film will resist yellowing over time, as the clear coat reflects UV rays and the new adhesive is less susceptible to heat degradation.

Custom laser cutting and new edge wrapping techniques will virtually eliminate film seams and edges, for a seamless transition and beautiful esthetic throughout your paint.

Reputable urethane film protection comes with a manufacturer warranty.

In most circumstances, the warranty is only valid if installed by a certified technician.

Avoid fresh paint. Clear bra should only be applied to painted surfaces that have fully cured.

The painted surface should be properly cleaned with an alcohol based solution and free of any contaminants, just prior to installation.

## POST PURCHASE

Once installed, let the film cure for 24 hours before attempting to maintain or manipulate it.

The film is designed to be removed and will not harm your paint upon removal.

The coating is not permanent. Current variations can be expected to last between 5 and 7 years.

Avoid using abrasives when trying to maintain the clear bra.

Wash the film with a designated, pH balanced, car soap and remember to wax, or seal, it for enhanced protection, longevity, esthetic.